

**850 SERIES  
GOOD ROPE/CHAIN ANCHOR WINDLASS  
INSTALLATION TEMPLATE**

**HOLE LAYOUT PATTERN  
& INSTALLATION  
MOUNTING INSTRUCTIONS FOR  
DECK OR PULPIT APPLICATION.**

- 1 - Locate windlass as far back on bow as anchor storage locker will allow.
- 2 - Align template center line with c'line of bow.
- 3 - Tape template to deck & transfer 6 holes.
- 4 - Drill 2, 3-1/8" diameter holes using a hole saw and 4, 11/32" diameter holes as marked.
- 5 - Chamfer, smooth all holes top & bottom.
- 6 - Be sure to seal thru-deck holes to prevent water intrusion.
- 7 - Install windlass head assembly.

**NOTE:**  
DECK THICKNESS IS 4" MAXIMUM FOR  
STANDARD APPLICATIONS. CONTACT FACTORY  
FOR EXTENSION MODIFICATION FOR HEAVIER  
DECK APPLICATION.

